

INSTALLATION METHOD.

Underlayment should be laid on concrete or mineral mortar with a moisture content not exceeding 3%.

Make sure the substrate is dry, clean and equal before you start of laying

The substrate should be insulated with a vapor barrier foil with a thickness of 0.2mm

Installation instructions:

The underlay should be laid loosely in rows with expansion joints (2mm) between the plates. In order to avoid sliding of the laid underlays and stabilizing the distance between them, underlays may be attached at some points with self-adhesive tape or the sticky tabs included in the package. By taking into account the distance from all fixed elements (walls, sills, pillars and other fixed structures) the width of the expansion joints should be up to 10 mm. The direction of laying underlay should be perpendicular to the direction of laying floor panels. The rough flooring planks should be laid with at least 50cm shift.

Notes:

1. The joints between the planks of rough flooring should not coincide with the joints of the surface floor panels.
2. The plate damaged by the fallen floor element or the sharp tool should be replaced.
3. Avoid walking on underlays without the floor laid on them, and if necessary in elastic sole and without a protector.